





TruLevel Bulkfill UT LEVELLER

TruLevel Bulkfill UT is a high build self levelling compound with excellent flow properties formulated for self-levelling differences from 3 to 70 mm in thickness on new or existing internal concrete substrates. It develops a smooth and even surface with high levels of mechanical resistance, ensuring the subsequent installation of floor coverings. It is ready to accept most floor coverings after approximately 24–36 hours and can be over coated with TruLevel Levelling compounds from 24 hours for quick and reliable installation. It is suitable for the application of carpet, carpet tiles, ceramic tile and floating floors finishes. TruLevel High Build is pumpable for ease of installation.

FEATURES & BENEFITS

Excellent Flow
 Thickness 3mm − 70mm
 Pump application

CLASSIFICATION ACCORDING TO EN 13813

The material properties of TruLevel Bulkfill UT is classified as CT-C30-F7 according to EN 13813

RECOMMENDED USE

Once dry suitable for the application of carpet, carpet tiles, ceramic tile and floating floors finishes and tile floor finishes. Not suitable for direct stick timber flooring application. It is ready to accept most floor coverings after approximately 24 hours and for resilient installations can be over coated with TruLevel Levelling compound.

TruLevel Bulkfill UT is pumpable and for internal applications and suitable for underfloor and heating systems.

SURFACE PREPARATION:

Subfloors must be dry, sound, clean and in accordance with the relevant Floorcoverings Australian Standards. Subfloors must also be free of wax, grease, oil, polishes, old adhesive, curing compounds, high levels of moisture and any other surface contaminants that may affect adhesion. If mechanical preparation is required prepare the floor using recommended preparation methods such as shot blasting, diamond grinding, to provide a roughened, clean, sound, and open porous surface. Thoroughly vacuum loose material and dust. The minimum subfloor temperature before commencing installation should be 10°C Do not use solvents, or acid etching to clean the subfloor. Concrete floors must be dry sound, smooth and clean, in accordance with relevant Floorcoverings Australian Standards. For subfloors that display high moisture levels it is recommended an RLA Moisture Barrier be applied. Please contact RLA Technical Department for further details. Where temperatures are less than 5°C or greater than 35°C are encountered, please contact RLA Technical department for further details.

PRIMING:

Prime concrete floors with TruLevel Universal Primer

Porous Substrates:

Absorbent concrete surfaces, Mix 1 Part Universal Primer with 2 Parts clean water.

Apply an even film using a roller or brush ensuring the entire area is primed and allow to cure.

Highly absorbent or porous surfaces may require a second coat of Universal Primer to avoid pinholes.

Non- Porous Substrates:

Ensure substrates such as sealed or burnished concrete substrates, ceramic tiles have no coatings or Curing and Sealing compounds residing on the surface before the application of primer. Coatings, Curing and Sealing compounds must be mechanically removed. For hard and tight substrates, it is recommended that a light grind or sand be conducted to enhance adhesion. Apply an even layer of Universal Primer NEAT Format (undiluted to non porous substrates).

Allow primer to dry (approx. 2 hours @ 23°C). Once Primer is a tack free clear film, Product can be applied over the primer.

Vinyl and Resilient applications:

When over coating, apply Universal Primer in neat format to the surface and allow too dry before the application of TruLevel Levelling Compound.

MIXING RATIO:

TruLevel Bulkfill UT Levelling compound should be mixed using a drill and suitable mixing paddle.

Mix one 20kg bag with 3.6–3.8 litres of clean water. Slowly add ½ the bag of powder to the water while mixing thoroughly, then add remainder of bag to mix. It is essential to ensure the powder and water are evenly mixed for approximately 3 minutes and the water is dispersed to obtain a lump free mix. Do not over water as this will promote bleed and separation with a reduction in bond and tensile strength.



APPLICATION:

Apply in one coat from 3mm to 70mm.

Apply the mixed compound to the primed substrate using a gauge rake, stand up spreader at the required height adjustment or trowel on a slight incline to obtain the required thickness. Larger installations can also be pumped using an appropriate mixing pump. It is recommended the mixed quantity be used within 15 minutes at a temperature of 23°C Due to its self—levelling properties will develop a smooth finish and even surface.

SETTING TIMES:

When applied will harden after approximately 3-4 hours at 23°C and can be walked on after this time.

The levelling coat will be ready to receive application of carpets, carpet tiles, floating floors and tile floor coverings fixed with adhesives after 24 hours at 23°C. Times may vary depending on Temperature, Humidity and Thickness.

If Vinyl or Rubber flooring is to be installed, we recommend installing a 2—3mm coat of TruLevel EconoPro or TruLevel TuffTop compound. Allow BulkFill UT to dry and then apply a coat of Universal Primer (NEAT) prior to installing the levelling compound.

CLEAN UP: Clean tools immediately after use with water

SHELF LIFE / STORAGE: 12 months when stored in original unopened packaging To be stored in a dry area off the ground. **NOTES & PRECAUTIONS:**

- Drving times can be extended when applied in cold ambient temperatures.
- Do not allow to come in contact with water during or after the curing process.
- Do not apply on substrates with rising damp.
- Internal use only.
- Do not apply overcoat until BulkFill UT is completely dry.
- Do not apply over expansion joints as reflective cracking may occur

TECHNICAL DATA:

PRODUCT INFORMATION	
Colour	Grey
Bulk Density (kg/dm ³)	1.34
Wet Density (kg/dm ³)	=2.100
Shelf life	12 months
Packaging	20kg
VOC – GEV Emicode	EC1 Plus
Coverage	Approximately 0.242 at 50mm

Application Data 23°C at 50% RH	
Mixing Ratio	3.6 – 3.8 litres water
Open Time	30-40 minutes
Setting Time	2–3 hours
Temperature Range	From +5°C to 35°C
Maximum Thickness	70mm
Foot traffic	3–4 hours
Time following bonding	24–36 hours
pH of Mix	Approximately pH 12

SAFETY & HANDLING

Do not breathe dust. Wear suitable respiratory protection.

Use in well ventilated areas. Avoid contact with skin and eyes.

Wear eye protection and suitable gloves and clothing.

Do not eat, drink or smoke while using this product. Take off contaminated clothing and wash before reuse.

If on skin wash with plenty of soap and water. If in eyes: rinse cautiously with water for several minutes.

Remove contact lenses, if present and easy to do. Continue rinsing.

If Inhaled remove victim to fresh air and keep at rest in a position comfortable for breathing.

If any skin or eye irritation persists or you feel unwell get medical attention.

Safety Data Sheet is available upon request.

WARRANTY STATEMENT:

RLA Polymers guarantees this product against manufacturing defects and guarantees it to be manufactured to our published specification. We certify that when fully cured this product is suitable for use and will perform as described in our technical data sheet or other published materials. RLA Polymers will replace product free of charge when purchased from any legally verifiable source, and where product is proven to have been stored, handled and install according to instructions published on our packaging and within the stated shelf life. The Installation of all materials must be carried out in accordance with the relevant Australian Standard and the Floorcovering Manufacturers instructions and the floorcoverings must have been subject to normal traffic conditions. Warranty doesn't not apply if damage, loss, failure to follow instructions or other circumstances are out of our control. Sufficient time and access to investigate any complaint must be accorded to RLA Polymers.

The consumer is responsible for any expenses incurred in making a claim.

A claim form can be requested by: Phone: 1800 242 931 Email: info@rlapolymers.com.au Mail: 215 Colchester Road Kilsyth Victoria 3137 (att Customer Service)

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits under our warranty are in addition to other rights and remedies available to the consumer under the law in relation to the goods and services to which the warranty relates.

Disclaimer

All Statements and technical information contained herein are based on tests we believe to be reliable but the accuracy thereof is not guaranteed.

Users assume all risk and liability resulting from the use of the product and must confirm the suitability thereof by their own tests. Conditions of Sale contain a limited warranty against manufacturing defects.

Issued: April 2020

Issue Date: 16/11/2021 Version: 1

Page 1 of 2



RLA Polymers Pty Ltd ACN 004 709 915 Head Office 215 Colchester Road Kilsyth, Victoria, 3137 Tel: 1800 242 931 New South Wales 363 Wentworth Ave Pendle Hill, N.S.W, 2145 Queensland 57 Fulcrum Street Richlands, QLD, 4077 Western Australia 24 Hanwell Way Bassendean, W.A, 6054 Tel: 08 9279 8911